PARTS LIST

No.	Description	Req'd.	Material	Part #
1	Stem & O-ring Holder	1	316 Stainless	19254SS
2	Seat O-ring	1	Tef-Sil	19033TS
3	Retainer Plate	1	316 Stainless	27443SS
4	Cap Screw ½"	4	316 Stainless	9Q4174
5	4x3 Body	1	316 Stainless	35729SS
	4x4 Body	1	316 Stainless	35826SS
	4x3 Jacket Body	1	316 Stainless	35831SS
	4x4 Jacket Body	1	316 Stainless	35827SS
6	Barrel Cap O-ring	1	Tef-Sil	18858TS/PFA
6a	Alternate Barrel Cap U-Cup	1	TFM/Elgiloy	75494SLTF
7	Shoulder O-ring	1	Tef-Sil	18592TS/PFA
8	Shoulder Washer	1	316 Stainless	76084SS
9	4x3 Actuator	1	316 Stainless	35233SSTS
	4x4 Actuator	1	316 Stainless	35224SSTS
10	Hex Nut ¼-20NC	4	316 Stainless	9Q5805
11	Lock Washer	4	316 Stainless	9Q5844
12	Cap Screw 1-1/2"	4	316 Stainless	9Q4919

No.	Description	Req'd.	Material	Part #
13	Spring Housing	ASSY	316 Stainless.	36054SSTS
A1	Housing Cap	1	316 Stainless	28244SS
A2	Base O-ring	1	Tef-Sil	75274TS
A3	Spring	1	316 Stainless	19413SS
A4	Washer	1	316 Stainless	19083SS
A5	Ring Retainer	1	302 Stainless	9Q4923
A6	Spring Washer	1	316 Stainless	75269SS
A7	Bushing Holder	1	316 Stainless	75268SS
A8	Bushing	1	PTFE/Glass	18467TG
A9	Packing Spring	1	302 Stainless	19050SL
A10	Packing Set	1	PTFE	8N2833
A11	Wiper	1	PTFE	18172TG
A12	Spider	1	316 Stainless	28341SS
A13	Cap Screw	4	316 Stainless	9Q5822A

- Actuator assembly (#9) includes barrel cap O-ring, shoulder O-ring, and shoulder washer (#6,7,8). If alternate barrel cap u-cup (#6a) is required, it must be order separately.
- Seal Kit for Spring Housing Assembly:
  CH75549TF - Includes items – A2, A8, A10, A11
- For instructions, see maintenance manual MM-CH001 for for Spring Housing, MM-CH002 for Valve, and MV-CH002 Valve maintenance video.
- Reference Engineering Bulletin (EB-01-20) for details.

WARNING: Use only genuine Betts Industries replacement parts. Substitute parts can impair the proper functioning of this product and void all warranties.