PARTS LIST

for RVP3NT and RVP4NT





No.	Description	Qty.	Material	Tank MAWP	Part Numbers	
					3" NPS	4" NPS
1	Pressure Disc	1	316L SS		28797SS	
2	Vent Body	1	316L SS		28795SS	
3	Mount	1	316L SS		28793SS	28791SS
4	Mounting Gasket	1	PTFE		75800TF-3	75800TF-4
5	Bearing Ring	2	Graphite/PTFE		75639TR3.15	
6	Main Seat O-Ring	1	FEP Encapsulated Silicone		75553TS	
7	Pressure Spring	1	Stainless Steel PTFE Coated	25 psig.	75809SSTF-25	
				30 psig.	75809SSTF-30	
				35 psig.	75809SSTF-35	
				40 psig.	75809SSTF-40	
8	Pressure Shroud	1	316 SS		28832SS	
9	Wave Ring	1	Stainless Steel		9Q5059	
10	Cyl. Cap O-Ring	1	FKM GFLTs		3357VF	
11	Cylinder Cap	1	316 SS		75818SS	
12	Lock Washer	1	Stainless Steel		9Q5844	
13	Safety Stop Screw	1	Stainless Steel		9Q5993	

Seal kit part number SK-RVPT incudes items 5, 6, 10, 12 and 13 only.
Spanner Wrench part number: 75825EY
Disassembly T-wrench part number: 75819ZC

MAINTENANCE: Valve should be inspected with sufficient frequency and due regard to the products carried. Any worn, damaged or missing parts must be replaced if their effectiveness is impaired in any way. Replacement O-rings and seals must be compatible with products carried. For additional information see Maintenance Manual MM-RV001 and Maintenance Video MV-RV001.

WARNING: Use only genuine Betts Industries replacement parts. Use of substitute parts can impair the proper function and safety of this product.