PARTS LIST

Deluxe Mechanical Operator



No.	Description	Material	Part No.				
			1 Compt.	2 Compt.	3 Compt.	4 Compt.	5 Compt.
1	Shaft	Brass	20790A	20790B	20790C	20790D	20790E
2	Roll Pin	Steel	9Q5816				
3	Trip Lever Assy.	Steel	20784A	20784B	20784C	20784D	20784E
4a	5/16-18 x 1” Bolt	Steel	9Q5829				
4b	5/16” Lock Washer	Steel	9Q5847				
4c	5/16” Nut	Steel	9Q5808				
5	Heavy Duty Dual Link	Steel	20716				
6	Link Clevis	Steel	10980				
7	Fusible Bushing Nut	Brass	19724BR				
8	Lock Nut	Steel	9Q5808A				
9	Adjusting Bolt	Steel	20040A*				
10	Clamping Nut	Steel	10268A				
11	Grease Fitting	Steel	9Z4871				
12a	Lever (center)	Steel	20725**	-	20725**	-	20725**
12bl	Lever (left hand)	Steel	-	41186L**	41186L**	41186L**	41186L**
12br	Lever (right hand)	Steel	-	41186R**	41186R**	41186R**	41186R**
12cl	Lever (left hand)	Steel	-	-	-	41187L**	41187L**
12cr	Lever (right hand)	Steel	-	-	-	41187R**	41187R**
13	Grip	Plastic	1856				

WARNING Use only genuine BETTS INDUSTRIES INC. replacement parts. Use of substitute parts can impair the proper function of this product.

Note: * Adjusting Bolt assembly 20040A001 includes items 7, 8, 9, and 10.
Note: ** Lever Assemblies (12a (bl, br, cl, cr)) include items 5, 6, and 11.

Betts™ INDUSTRIES, INC. WARREN, PA.
Tel. (814) 723-1250 · Fax (814) 723-7030 · E-Mail: betts@bettsind.com · Web Site: www.bettsind.com